



Turning the Power On and Off

- Turning the power on
Hold down  for at least one second.
- Turning the power off
Hold down  for at least two seconds.

Applying the EZweb Default Settings






To send and receive e-mail or use EZweb, you must first subscribe to EZweb. You should also apply the default settings before sending and receiving e-mail or using EZweb. Applying the default settings automatically sets your e-mail address.

From the stand-by screen: Press  → Press  [OK] (to begin applying the default settings). → Press  [OK] .











Checking Your Own Phone Number/E-mail Address

From the stand-by screen: Press  . → Press  (displays your own phone number and e-mail address in the profile).









Making and Answering a Call

- Making a call
From the stand-by screen: Enter the phone number you want to call. → Press  .
To end the call: Press  .
- Answering a call
When the phone rings, press  .
To end the call: Press  .
To adjust the earpiece volume: Press  .


Storing and Recalling Address Book Entries

- Storing an entry
From the stand-by screen: Press  and press  [新規] (New). → Enter the name and press  [OK] . → Select 「直接入力」 (Enter directly) and press  [選択] (Select). → Enter the phone number and press  [OK] . → Select 「入力しない」 (No entry) and press  [選択] (Select). → Check the details and press  [登録] (End).
- Recalling an entry
From the stand-by screen: Press  . → Press  to select the desired name. → Press  .

Sending and Receiving (Reading) E-mails


- Sending an e-mail
From the stand-by screen: Press  , select 「Eメール」 (e-mail) and press  [選択] (Select). → Select 「新規作成」 (New) and press  [選択] (Select). → Select 「直接入力」 (Enter directly) and press  [選択] (Select). → Enter the recipient's e-mail address, the subject and the message by following the on-screen instructions. → Press  [送信] (Send).
- Receiving (reading) e-mail
When you receive e-mail, the phone emits the incoming e-mail tone and displays the new e-mail message 「新着Eメール△件」 (You have △ new e-mails) on the stand-by screen.
Select 「新着Eメール」 (New) and press  [確認] (Check). → Select the folder and press  [選択] (Select). → Select the e-mail you want to read and press  [表示] (Display).

Using the Camera (Photos)

From the stand-by screen: Press  , select 「フォト(壁紙)」 (Photo(Wallpaper)) and press  [選択] (Select) → Press  [撮影] (Shoot). → Press  [保存] (Store).

Making an International Call

E.g.: To call 212-123-△△△△ in the USA



Other Handy Features

● Manner Mode

From the stand-by screen: Hold down  for at least one second.

To disable Manner mode, repeat the above step.

● Take a Message

- Setup

From the stand-by screen: Hold down  for at least one second.

To disable Take a Message, repeat the above step.

- Playback

From the stand-by screen: Press . → Select 「メモ再生」 (Play message) and press 

【選択】. → Select the message you want to listen to and press  【再生】 (Play).

For inquiries, please contact

au Customer Service Center (General Information)

- If you are calling from a landline phone: ☎0077-7-1111 (toll free)
- If you are calling from an au mobile phone: 157 (toll free)